



# **Owner's Manual Supplement**

www.seafoxboats.com

#### **SEA FOX BOAT'S DISCLAIMER**

The following Owner's Manual is provided for information and educational purposes only and is not intended to offer or provide legal advice or create a contractual relationship between Sea Fox Boat Company and the owner of any Sea Fox brand vessel. Please beware that as a vessel owner you have non-delegable responsibilities regarding the safety, maintenance, fitness, and operation of your vessel and the extent of such responsibilities is ultimately determined by Federal law and regulations, the general maritime law of the United States, the laws and regulations of the states and territories of the United States, or the laws and regulations of the country where you operate your vessel. To fully understand your responsibilities as a vessel owner, and before operating or letting any third-party operate your vessel, we recommend that you consult the services of a qualified lawyer in admiralty and maritime law.



### **TABLE OF CONTENTS**

Introduction	Electrical Schematics	14
Specifications	Main Harness	. 14
Designated Occupant Seating4	Switch Panel	. 15
Safety Decals5	Breaker Panel	. 16
Plumbing Schematics	Deck Harness	. 18
Fuel System7	Hardtop Harness	. 19
Bilge System	Underwater Lights Harness	. 20
Fresh Water System9	Windlass Cables Harness	. 21
Raw Water System	Windlass Deck Harness	. 22
Drains11	Windlass Switch Panel	. 23
Livewell System12	Windlass Deck Bow Panel	. 24
Electric Head System	Electric Head Harness	. 25
	Battery Wiring	. 27



This Page Intentionally Left Blank



#### INTRODUCTION

Congratulations and Welcome Aboard! With so many boat brands to choose from, we want to congratulate you on your decision to choose Sea Fox Boats. For more than 24 years, Sea Fox offers the finest hand-crafted saltwater boats carefully balanced with the build-quality, features, styling and performance for the fairest price. Our passion for boating is evident in every model we make and we appreciate that you've noticed the Sea Fox difference.

We share your love for the moments spent on the water with friends and family, which is why every Sea Fox boat offers a unique blend of fishing/family options, technologies and innovative features. Your choice of a Sea Fox affirms that you have performed your research and compared the value of your model with the competition.

Whether you are new to the boating lifestyle or an old salt, we ask that **you and all other operators** read the owner's manual, this supplement, and all other literature provided with the boat **before** operating the boat or any equipment. We also recommend that all operators enroll in a boating safety course available online - see References and Contact Information in this section for education resources online.

This supplement contains model-specific information not included with the owner's manual. This manual is not intended to be a replacement for specific product literature provided by engine, accessory or other major equipment manufacturers, but rather to supplement that information.

Because of our philosophy of continuous product improvement, this manual serves as a general guide only, so the specifications and illustrations used may not match the equipment on your boat and are intended only as general reference views.

We welcome you to the Sea Fox family and wish you many years of boating enjoyment!


#### **SPECIFICATIONS**

Max. Weight Capacity	Yacht Certification	
Persons	Yacht Certification	
Persons Weight	Yacht Certification	
Max. HP	450 hp (335 kw)	
L.O.A.	26' (7.9 m)	
Beam	9' 3" (2.8 m)	
Draft	16 in. (0.41 m)	
Height, Keel to Top (Light Folded)	118 in. (3 m)	
Bridge Clearance Hard Top	102 in. (2.59 m)	
Max. Weight Boat (w/ Fluids, Largest HP)	7644 lbs (3467 kg)	
Fuel Tank Capacity	139 gal (526 L)	
Freshwater Tank Capacity	12 gal (45 L)	
Holding Tank Capacity	12 gal (45 L)	
•	-	



#### **DESIGNATED OCCUPANT SEATING**

Be sure all passengers are properly seated in designated seating positions and not riding on the bow, bow pulpit, deck, gunwale or rear sun deck while underway. Passengers must use hand-holds and use caution when riding in the bow. Move to the aft passenger seats during rough water operation or if visibility is restricted.



#### **CAPACITY INFORMATION**

Yacht Certified

Recommended seating

Max HP: 400 HP (298 kW)

= Seat position

SFOX-0024a

### **SER JFOX**

#### **BOAT WORKS**

#### SAFETY DECALS





### **SER** \(\text{FOX}\)

BOAT WORKS

YACHT CERTIFICATION THIS BOAT COMPLIES WITH THE U.S. COAST GUARD SAFETY STANDARDS IN EFFECT ON THE DATE OF CERTIFICATION **SEA FOX BOAT COMPANY** MONCKS CORNER, S.C.

A DANGER

WATER

ARBON MONOXIDE (CO) CAN CAUSE BRAIN AMAGE OR DEATH.

Signs of carbon monoxide poisoning include nausea, headache, dizziness, drowsiness, and lack of

JSE AVAILABLE HANDRAILS AND HANDHOLDS

Carbon monoxide can be present in the cabin.

MOVE TO FRESH AIR if anyone shows signs of carbon monoxide poisoning.

hile moving about the cabin and otion to avoid falling.



**NOTICE** 

THIS BOAT IS EQUIPPED WITH

AN OPTIONAL DIRECT OVERBOARD

DISCHARGE VALVE. DISCHARGING

OF SEWAGE DIRECTLY OVERBOARD

IS FOR USE WHERE APPROVED ONLY

#### **WARNING**

WARNING

CONTENTS CAN BE UNDER PRESSURE.

AVOID SERIOUS INJURY OR DEATH

FROM FIRE OR EXPLOSION.

NO SMOKING OR OPEN FLAMES.

AVOID PERSONAL INJURY SECURE GATE/DOOR & DO NOT BE OUTSIDE GATE/DOOR WHEN BOAT IS LINDERWAY

GAS / PETROL

E-15

#### Failure to follow these warnings could cause severe injury or d WEAR SAFETY LANYARD at all times while operating boat to prevent unmanned boat operation NEVER OPERATE WHILE LINDER THE INFLUENCE

DO NOT OVERLOAD THE BOAT. ENSURE THAT WEIGHT IS PROPERLY AND EVENLY DISTRIBUTED fore and aft and on both sides of the boat to avoid poor handling sudden loss of control, swamping and/or capsizing. PASSENGERS SHOULD WEAR U.S. COAST GUARD APPROVED LIFE JACKETS

A WARNING

MAKE SURE THAT ALL PASSENGERS ARE PROPERLY SEATED WHILE UNDERWAY. To avoid passengers falling overboard or being ejected from the boat, do not allow passengers to sit on seat backs.

gunwales or outermost deck edges while boat is moving REDUCE SPEED BEFORE ATTEMPTING SUDDEN OR SHARP TURNS.

AND MAINTAIN SAFE SPEEDS for water conditions and environment at all

KEEP PROPER LOOKOUT AND SAFE DISTANCE for the conditions at all times to avoid collisions.

 OBEY APPLICABLE NAVIGATION RULES AND BOATING LAWS.

USE CAUTION AND PROPER LIGHTING during nighttime boating and

READ THE OWNER'S MANUAL AND COMPLETE THE BOATER'S PRE-OPERATION CHECKLIST prior to boat operation.

...



SHUT OFF VALVE(S) LOCATED BEHIND ACCESS PANEL. CLOSE VALVE(S) WHEN NOT IN USE.





AVOID PERSONAL INJURY Ladder person capacity not to exceed 400 lbs. Insure ladder is secure to mount before use. Keep hands and feet clear of moving parts while stowing and deploying.



AVOID PERSONAL INJURY SECURE GATE/DOOR WHEN BOAT IS UNDERWAY. ENSURE LADDER IS SECURED TO DECK PRIOR TO USING IF EQUIPPED.

9

**x2** 

(3)

fingers when opening

and closing cover



ROTATING PROPELLER CAN

CAUSE SERIOUS INJURY OR DEATH. SHUT OFF MOTOR

WHEN NEAR PERSONS IN

WATER Manufactured by **SERUFOX** 

BOAT WORKS

(9)

**(6)** 

(9)



#### WARNING



Leaking fuel is a fire and explosion hazard.

Avoid serious injury or death from fire or oplosion from leaking fuel. Inspect system for leaks at least once a year



#### (5) RAW WATER

#### WARNING

Failure to follow these warnings could cause SERIOUS INJURY or DEATH



DO NOT OVERLOAD THE BOAT. OCCUPANTS AND GEAR MUST BE PROPERLY AND EVENLY DISTRIBUTED fore and aft, and on both sides of the boat. Improper loading and/or overloading may result in poor handling, sudden loss of control, swamping and/or capsizing.

- REFER TO AND OBEY THE DESIGNATED OCCUPANT SEATING POSITIONS that are indicated by the manufacturer for your specific mode
- OREY THE OPERATOR at all times
- DO NOT RESTRICT THE OPERATOR'S VISION
- DO NOT DEPART THE VESSEL without informing the operator

NO WOOD! NO ROT!



**A** WARNING Operating, servicing and maintaining a recreational marine vessel can expose you to chemicals including engine exhaust, carbon monoxide, on that are known to the State of California to cause that are known to the State of California to cause the state of California to cancer and birth defects or other reproductive harm. To minimize expos void breathing exhaust, service your vessel in a well-ventilated area and vear gloves or wash your hands frequently when servicing this vessel.

For more information go to www.P65warnings.ca.gov/marine **A** DANGER

Carbon monoxide (CO) can cause brain damage or death.

Engine and generator exhaust contains odorless nd colorless carbon monoxide gas. Carbon monoxide will be around the back of the boat when engines or generators are running. Move to fresh air, if you feel nausea, headache, lizziness, or drowsiness.

### DISCHARGE OF OIL PROHIBITED

THE FEDERAL WATER POLLUTION CONTROL ACT PROHIBITS THE DISCHARGE OF OIL OR OILY WASTE INTO OR UPON THE NAVIGABLE WATERS OF THE UNITED STATES, OR THE WATERS OF THE CONTIGUOUS ZONE, OR WHICH MAY AFFECT NATURAL RESOURCES BELONGING TO, APPERTAINING TO, OR UNDER THE EXCLUSIVE MANAGEMENT AUTHORITY OF THE UNITED STATES, IF SUCH DISCHARGE CAUSES A FILM OR DISCOLORATION OF THE SURFACE OF THE WATER OR CAUSES A SLUDGE OR EMULISION RENEATH THE SURFACE OF THE WATER, VIOLATORS ARE SUBJECT TO SUBSTANTIAL CIVIL PENALTIES AND/OR CRIMINAL SANCTIONS INCLUDING FINES AND IMPRISONMENT.

#### (3) A WARNING

P

Rotating propeller may cause serious injury or death Shut off engine when near persons in the water. Carbon monoxide (CO) can cause brain damage or death.

Engine and generator exhaust contains odorless and colorless carbon monoxide gas. Signs of carbon monoxide poisoning include nausea, headache, dizziness, drowsiness, and lack of consciousness. Get fresh air if anyone shows signs of carbon monoxide

ee Owner's Manual for information regarding carbon monoxid



Leaking fuel is a fire and explosion hazard. Avoid serious injury or death from fire or explosion from leaking fuel. Inspect system for leaks at least once a year

SEA FOX BOAT COMPANY
MEETS U.S. EPA EVAP STANDARDS USING CERTIFIED COMPONENTS

#### Failure to follow these warnings could cause SERIOUS INJURY or DEATH REMAIN PROPERLY SEATED AND HOLD ON WARNING





**A WARNING** 

REFER TO AND OREY THE DESIGNATED OCCUPANT SEATING

OBEY THE OPERATOR at all times.

DO NOT RESTRICT THE OPERATOR'S VISION. DO NOT DEPART THE VESSEL without informing the operato It is illegal for any vessel to dump plastic ANYWHERE in the ocean or navigable waters of the United States nnex V of MARPOL TREATY is an International Law for a cleaner, safer marine environment. Violation of the requirements is a Class D Felony and may result in a civil penalty, up to \$25,000 fine and imprisonment.

U.S. lakes, rivers, bays or sounds 3 to 12 miles 12 to 25 miles Outside 25 miles and 3 miles from shore ILLEGAL TO DUMP ILLEGAL TO DUMP ILLEGAL TO DUMP: ILLEGAL TO DUMP: Plastic Plastic Plastic

Plastic and Garbage Dunnage, lining and packing Paper Metal materials that float; also if not ground to less than one inch Rags Crocker Glass Dunnage Paper Crockery Food Glass Food

Regional state and local regulations may further restrict the disposal of garbage. The discharge of all garbage into the Great Lakes or their connecting or tributary waters is prohibited.


230263 231 Bay Fox Decal Kit Rev 3


Dunnage, lining and packing

materials that float.

### **SER** \( \subseteq \text{FOX} \)

**BOAT WORKS** 





A- AFT SLING LOCATION PORT AND STARBOARD

(28")

B- FORWARD SLING LOCATION PORT AND STARBOARD


(180")






#### **PLUMBING SCHEMATICS**


#### **FUEL SYSTEM**








#### **BILGE SYSTEM**






#### FRESH WATER SYSTEM






#### **RAW WATER SYSTEM**







#### **DRAINS**






#### LIVEWELL SYSTEM








#### **ELECTRIC HEAD SYSTEM**





#### **ELECTRICAL SCHEMATICS**

#### **MAIN HARNESS**



UPM# SFX-268-0059

STBD TAB 2-22 BLK

INDICATOR DT06-2S

**BILGE COMPARTMENT** 

SF#: 7867

10G RED/WHT

TO AFT BREAKER PANEL

268CC ACCESSORY HARNESS

12 ORG

TO OVERBOARD MAC PUMP . JERBUAKD MAC PUN 12 BRN/BLK12 BLK#OVRBRD PUMP

12 ORG/RED-PWR IN 12 ORG ELCT HEAD 16 YEL SOLINOID

Combine yellow to org

12 BRN/BLK-PWR IN 12 BRN/BLK-TO PUMP

WHEN TOILET FLUSHES

SAME FOR 256-286

POWERS UP

BATTERY SWITCH STBD SIDE

CONSOLE

to Nov Horn 14 GRY/GRN-NAV 14 BLK #NAV

LABEL STBD TAB 1-22 GRN

INDICATOR

CONSOLE


STBD TAB 2-22 BLK INDICATOR

to Nov Horn

14 GRY/GRN-NAV 14 BLK #NAV




#### **SWITCH PANEL**



ADD 6 SHOULDER WASHERS
IN A BAG AND SEND W/PANEL




#### **BREAKER PANEL**






#### **BREAKER PANEL (CONTINUED)**





#### **DECK HARNESS**




6 SPEAKER STEREO, NAV, MOOD LIGHT HARNESS




#### HARDTOP HARNESS

# **HARDTOP**




SFX-031H1 PLUG INTO MAIN





#### **UNDERWATER LIGHTS HARNESS**

## UNDER WATER LIGHT OPTION



Under Water Light Harness, SF# 7930




#### WINDLASS CABLES HARNESS

### LABEL CABLE ENDS











#### **WINDLASS DECK HARNESS**






#### **WINDLASS SWITCH PANEL**



### **SER** UFOX

**BOAT WORKS** 

#### WINDLASS DECK BOW PANEL






#### **ELECTRIC HEAD HARNESS**

## TOILET OPTION

.090 ALUM GLOSS BLK POWDERCOAT WHITE SCREEN TEXT




### **SEA DFOX**

**BOAT WORKS** 


#### **ELECTRIC HEAD HARNESS (CONTINUED)**

## TOILET OPTION





#### **BATTERY WIRING**





This Page Intentionally Left Blank

